



PDF
Complete

Your complimentary
use period has ended.
Thank you for using
PDF Complete.

[Click Here to upgrade to
Unlimited Pages and Expanded Features](#)

VOOR GEBRUIK BUITENSHUIS

kan gevaarlijk zijn en is VERBODEN
te gebruiken
volgens het toekomstig lokaal geldende wet- en regelgeving

FOR OUTDOOR USE ONLY

- Close the valve of the gas cylinder or the regulator after use
- The use of this appliance in enclosed areas can be dangerous and is PROHIBITED.
- Read the instructions before using this appliance
- The appliance must be installed in accordance with the instructions and local regulations.

WERKING

Flameheater ontsteken

1. Draai gaskraan op gasfles helemaal open
2. Druk bedieningsknop in en draai 90° tegen de klok in op positie (waakvlam)
3. Houd bedieningsknop 30 seconden ingedrukt en druk ondertussen op ontstekingsknop tot de waakvlam ontsteekt. Houd bedieningsknop nog 30 seconden ingedrukt om thermokoppel tijd te geven gascircuit open te houden, laat dan los. Als waakvlam dooft, procedure herhalen.

Let op:

- Na aansluiting nieuwe gasfles lucht in de leidingen minstens één minuut tijd geven te ontsnappen via opening waakvlam
 - Bij ontsteken waakvlam bedieningsknop ingedrukt houden terwijl u de ontstekingsknop indrukt. Pas als de waakvlam brandt de bedieningsknop loslaten.
 - U kunt de waakvlam zien onderin de brander, tegenover de bedieningsknop.
 - Als de waakvlam weer dooft, procedure 3 herhalen
4. Als de waakvlam brandt kunt u de bedieningsknop op "LO" (laag) of "HI" (hoog) draaien.

Flameheater doven

5. Draai bedieningsknop op positie ⚡ (waakvlam)
6. Druk knop in en draai op positie "OFF" (uit)
7. Draai de gaskraan op de gasfles helemaal dicht

Dit apparaat is uitgevoerd met een voorziening die de gastoevoer naar de heater onmiddellijk afsluit wanneer het apparaat meer dan 40° overhelt.

Na uitschakeling de branderomgeving niet aanraken tot het apparaat is afgekoeld (± 45 min.).

OPERATION

Turn on flameheater

1. Turn on the valve of the LPG Gas Cylinder completely.
2. Press and turn the control knob (counter-clockwise 90°) to position ⚡ "PILOT"
3. Press down the control knob and hold for 30 seconds. While holding down the control knob, press the igniter button several times until the pilot flame alights. Keep to press in the way to give time to the thermocouple to keep open gas circuit (30 seconds). Release the control knob. If pilot does not keep alight, do the same procedure again.

Note:

- If a new LPG Gas Cylinder has just been connected, please allow at least one minute for the air in the gas pipeline to purge out through the pilot hole.
 - When lighting the pilot flame make sure that the pilot light button is continuously pressed down while pressing the igniter button. Pilot light button can be released after the pilot flame lights.
 - Pilot flame can be watched and checked at the burner, in front of the control knob
 - If the pilot flame does not light or it goes out, repeat step 3.
4. After the pilot flame alights, turn the control knob from minimum position "LO" to maximum position "HI".

Turn off the heater

5. Rotate the control knob to position "PILOT".
6. Press and turn the variable control knob to position "OFF".
7. Turn off the valve on the LPG Gas Cylinder completely.

The appliance is fitted with a special device that extinguishes immediately gas to the appliance, if the appliance is tilted more than 40°.

After shut-off, do not touch burner assembly until appliance has cooled (not before 45 minutes after shut-off).